
NSX-WVT99 HR



SERVICE MANUAL

COMPACT DISC STEREO CASSETTE RECEIVER

BASIC TAPE MECHANISM: 2ZM-3MK2 PR4NM BASIC CD MECHANISM: 6ZG-1 VZRNDM

SYSTEM	CD CASSEIVER	SPEAKERS	REMOTE CONTROL
NSX-WVT99	CX-NWVT99	SX-WWVT79 SX-R2700 SX-C2700	RC-ZAS08

- This Service Manual is the "Revision Publishing" and replaces "Simple Manual" NSX-WVT99, (S/M Code No. 09-004-430-7T1).
- If requiring information about the CD mechanisim, see Service Manual of 6ZG-1, (S/M Code No. 09-001-338-7N4)



SPECIFICATIONS

<FM Tuner section>

Tuning range 87.5 MHz to 108 MHz

Usable sensitivity(IHF) 13.2 dBf

Antenna terminals 75 ohms (unbalanced)

<MW Tuner section>

Tuning range 531 kHz to 1602 kHz (9 kHz step)

530 kHz to 1710 kHz (10 kHz step)

Usable sensitivity 350 uV/m

Antenna Loop antenna

<SW Tuner section>

Tuning range 5.73 MHz to 17.9 MHz

Antenna Wire antenna

<Amplifier section>

Mid-high frequency amplifier Front

Power output* Rated: 80 W + 80 W

(8 ohms, THD 1 %,1 kHz) Reference: 100 W + 100 W (8 ohms, THD 10 %,1 kHz)

Total harmonic distortion 0.3 % (40 W, 1 kHz, 8 ohms,

DIN AUDIO)

LOW FREQ+SUB WOOFER amplifier

Power output* Rated: 200 W + 200 W

(8 ohms, THD 1 %,75 Hz) Reference: 250 W + 250 W (6 ohms, THD 10 %,75 Hz)

Total harmonic distortion 0.3 % (100 W, 75 Hz, 6 ohms,

DIN AUDIO) Rear (Surround) Rated: 80 W + 80 W (8 ohms, THD 1 %,1 kHz) Reference: 100 W + 100 W (8 ohms, THD 10 %,1 kHz)

Center

Rated: 80 W (8 ohms, THD 1 %,

1 kHz)

Reference: 100 W (8 ohms, THD

10 %,1 kHz)

VIDEO/AUX: 300 mV (adjustable) Inputs

MD: 300 mV (adjustable) MIC 1, MIC 2:1.0mV (10 kohms)

5.1CH INPUT:

FRONT (L,R): 240 mV SURROUND (L,R): 240 mV CENTER: 600 mV SUB WOOFER: 240 mV

LINE OUT: 150 mV **Outputs**

VIDEO OUT: 1.0V p-p (75 ohms)

SPEAKERS HIGH FREQ:

accept speakers of 8 ohms or more SPEAKERS (LOW FREQ +SUB WOOFER): accept speakers of 6

ohms or more

SURROUND SPEAKERS: accept speakers of 8 ohms to 16 ohms CENTER SPEAKER: accept speakers of 8 ohms or more PHONES (stereo jack): accepts headphones of 32 ohms or more

<Cassette deck section>

Track format

4 tracks, 2 channels stereo Frequency response CrO2 tape: 50 Hz - 16000 Hz Normal tape: 50 Hz - 15000 Hz

Signal to noise ratio 60dB (Dolby B NR ON, CrO2 tape

peak level)

Recording system

Heads

Deck 1: Playback head x 1

Deck 2: Recording/Playback head

x 1, erase head x 1

<Compact disc player section>

Laser Semiconductor laser (λ =780 nm)

D-A converter 1 bit dual

Signal-to-noise ratio 83 dB (1 kHz, 0 dB) Harmonic distortion 0.05 % (1 kHz, 0 dB) Wow and flutter Crystal accuracy Video signal NTSC/PAL color format

(selectable)

Video data MPEG 1

Audio data MPEG 1, LAYER 2

<Speaker system SX-WWVT79>

Cabinet type 4 way, built-in subwoofer (magnetic shielded type)

Speakers Subwoofer:

> 200 mm (7⁷/_o in.) cone type Woofer: 120 mm (43/4 in.) cone type

Tweeter:

60 mm (2^{3} / $_{8}$ in.) cone type

Super Tweeter:

20 mm (13/16 in.) ceramic type

6 ohms / 8 ohms Impedance Output sound pressure level 87 dB/W/m

Dimensions (W \times H \times D) 260 x 383 x 326 mm

 $(10^{1}/_{4} \times 15^{1}/_{8} \times 12^{7}/_{8} \text{ in.})$ 7.5 kg (16 lbs 9 oz)

<Speaker system SX-R2700>

Speakers Full range:

100 mm x 2, cone type

Impedance 8 ohms

Dimensions (W x H x D) 120 x 230 x 110 mm

 $(4^3/_4 \times 9^1/_8 \times 4 \text{ in.})$

Weight 1.2 kg (2 lbs 10 oz)

<Speaker system SX-C2700>

Speakers Full range: (Magnetic Shielded Type)

100 mm x 2, cone type

Impedance 8 ohms

Dimensions (W x H x D) 360 x 120 x 110 mm

 $(14^{1}/_{4} \times 4^{3}/_{4} \times 4 \text{ in.})$

Weight 1.9 kg (4 lbs 3 oz)

<General>

Weight

Power requirements 120V/220-230 V/240 V AC

switchable, 50/60 Hz

Power consumption 390W

Dimensions of main unit 300 x 383.5 x 380 mm $(W \times H \times D)$ $(11^{7}/_{8} \times 15^{1}/_{8} \times 15 \text{ in.})$ Weight of main unit 18 kg (39.6 lbs)

Standby power consumption

If the power-economizing mode is OFF: 47 W If the power-economizing mode is ON: 0.9 W

• Design and specifications are subject to change without notice.

• Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation

"DOLBY" and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

• The word "BBE"and the "BBE symbol" are trademarks of BBE Sound, Inc.

Under license from BBE Sound, Inc.

PROTECTION OF EYES FROM LASER BEAM DURING SERVICING

This set employs laser. Therefore, be sure to follow carefully the instructions below when servicing.

WARNING!!

WHEN SERVICING, DO NOT APPROACH THE LASER EXIT WITH THE EYE TOO CLOSELY. IN CASE IT IS NECESSARY TO CONFIRM LASER BEAM EMISSION. BE SURE TO OBSERVE FROM A DISTANCE OF MORE THAN 30cm FROM THE SURFACE OF THE OBJECTIVE LENS ON THE OPTICAL PICK-UP BLOCK.



 Caution: Invisible laser radiation when open and interlocks defeated avoid exposure to beam.

Advarsel: Usynlig laserståling ved åbning, når sikkerhedsafbrydere er ude af funktion. Undgå udsættelse for stråling.

VAROITUS!

Laiteen Käyttäminen muulla kuin tässä käyttöohjeessa mainitulla tavalla saataa altistaa käyt-täjän turvallisuusluokan 1 ylittävälle näkymättömälle lasersäteilylle.

VARNING!

Om apparaten används på annat sätt än vad som specificeras i denna bruksanvising, kan användaren utsättas för osynling laserstrålning, som överskrider gränsen för laserklass 1.

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herin may result in hazardous radiation exposure.

ATTENTION

L'utillisation de commandes, réglages ou procédures autres que ceux spécifiés peut entraîner une dangereuse exposition aux radiations.

ADVARSEL

Usynlig laserståling ved åbning, når sikkerhedsafbrydereer ude af funktion. Undgå udsættelse for stråling.

This Compact Disc player is classified as a CLASS 1 LASER product.

The CLASS 1 LASER PRODUCT label is located on the rear exterior.

CLASS 1 LASER PRODUCT
KLASSE 1 LASER PRODUKT
LUOKAN 1 LASER LAITE
KLASS 1 LASER APPARAT


Precaution to replace Optical block

(KSS-213F)

Body or clothes electrostatic potential could ruin laser diode in the optical block. Be sure ground body and workbench, and use care the clothes do not touch the diode.

1) After the connection, remove solder shown in right figure.

PICK-UP Assy P.C.B



NOTE ON BEFORE STARTING REPAIR


1. Forced discharge of electrolytic capacitor of power supply block

When repair is going to be attempted in the set that uses relay circuit in the power supply block, electric potential is kept charged across the electrolytic capacitors (C101, 102) even though AC power cord is removed. If repair is attempted in this condition, secondary defect can occur.

In order to prevent the secondary trouble, perform the following measures before starting repair work.

Discharge procedure

- **1** Remove the AC power cord.
- ② Connect a discharging resistor at an end of lead wire that has clips at both ends. Connect the other end of the lead wire to metal chassis.
- **3** Contact the other end of the discharging resistor to the positive (+) side (+VH) of C101. (For two seconds)
- Ocontact the same end of the discharging resistor as step to the negative (-) side (-VH) of C102 in the same way. (For two seconds)
- S Check that voltage across C101 and C102 has decreased to 1 V or less using a multimeter or an oscilloscope.



Select a discharging resistor referring to the following table.

Fig-1

(Charging voltage (V) (C101, 102)	Discharging resistor (Ω)	Rated power (W)	Parts number
	25-48	100	3	87-A00-247-090
	49-140	220	5	87-A00-232-090

Note: The reference numbers (C101, C102) of the electrolytic capacitors can change depending on the models. Be sure to check the reference numbers of the charging capacitors on schematic diagram before starting the discharging work.

2. Check items before exchanging the MICROCOMPUTER

Be sure to check the following items before exchanging the MICROCOMPUTER. Exchange the MICROCOMPUTER after confirming that the MICROCOMPUTER is surely defective.

2-1. Regarding the HOLD terminal of the MICROCOMPUTER

When the HOLD terminal (INPUT) of the MICROCOMPUTER is "H", the MICROCOMPUTER is judged to be operating correctly. When this terminal is "L", the main power cannot be turned on. Therefore, be sure to check the terminal voltage of the HOLD terminal before exchange.

When the MICROCOMPUTER is not defective, the HOLD terminal can also go "L" when the POWER AMPLIFIER has any abnormalities that triggers the abnormality detection circuit on the MAIN C. B. that sets the HOLD terminal to "L".

Good or no good judgement of the MICROCOMPUTER

- 1 Turn on the AC main power.
- ② Confirm that the main power is turned on and the HOLD terminal of the MICROCOMPUTER keeps the "H" level or not.
- **3** When the HOLD terminal is "L" level, the abnormality detection circuit is judged to be working correctly and the MICROCOMPUTER is judged to be good.




Fig-2-1

In such a case, check also if the POWER AMPLIFIER circuit or power supply circuit has any abnormalities or not.

2-2. Regarding reset

There are cases that the machine does not work correctly because the MICROCOMPUTER is not reset even though the AC power cord is re-inserted, or the software reset (pressing the STOP key + POWER key) is performed.

When the above described phenomenon occurs, it can lead to wrong judgement as if the MICROCOMPUTER is defective and to exchange the MICROCOMPUTER. In such a case, perform the forced-reset by the following procedure and check good or no good of the MICROCOMPUTER.

① Remove the AC power cord.




Fig-2-2

- ② Short both ends of the electrolytic capacitor C113 that is connected to VDD of the MICROCOMPUTER with tweezers.
- 3 Connect the AC power cord again. If the MICROCOMPUTER returns to the normal operation, the MICROCOMPUTER is good.

Note: The reference number or MICROCOMPUTER pin number of transistor (Q110) and electrolytic capacitor (C113) can change depending on the models. Be sure to check the reference numbers on schematic diagram before starting the discharging work.

2-3. Confirmation of soldering state of MICROCOMPUTER

Check the soldering state of the MICROCOMPUTER in addition to the above described procedures. Be sure to exchange the MICROCOMPUTER after surely confirming that the trouble is not caused by poor soldering but the MICROCOMPUTER itself.

ELECTRICAL MAIN PARTS LIST

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION		REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
IC	8A-NH3-635-010 87-A21-482-010 87-A20-869-040 87-A21-355-010	C-IC,LC IC,RPM6 C-IC,M6	2449FP			87-A40-768-080 87-017-154-080 87-A40-749-080 87-A40-488-080 87-020-331-080	ZENER, ZENER, DIODE,	UZ16BSA HZS6C3L UZ5.6BSB 1SS244 IODE,DAN202K
	87-A20-355-010 87-A20-561-040 87-A20-783-040	IC,CXA1 C-IC,M6 C-IC,BA	553P 5847AFP 7762AFS			87-A40-313-080 87-A40-270-080 87-A40-751-080 87-A40-392-010	C-DIOD ZENER, DIODE,	
	87-A21-577-040 87-070-289-040 87-A21-021-040 87-A21-015-040	IC,BU 2 C-IC,BU	092F 2099FV			87-A40-269-080 87-A40-747-080 87-A40-646-010 87-A40-224-010	ZENER, DIODE,	E,MC2836 UZ5.1BSB FMB-G16L GBU8DL
	87-A21-452-030 87-A21-560-010 87-070-127-110 87-020-454-010	C-IC,BD IC,LA18 IC,LC72	3876KS2 44L-A 131 D			87-A40-784-080 87-A40-760-080 87-A40-764-080	ZENER, ZENER, ZENER,	UZ398BSB UZ9.1BSA UZ10BSC
	87-A21-051-040 87-A21-097-040		9990-03FS 2463AFP			87-017-149-080 87-A40-393-090		HZS6A2L 1N5402GW(F20)
TRANSISTO	R			N	MAIN C.B			
	87-026-245-080 87-A30-217-010 87-A30-198-080 89-213-702-010 87-A30-218-080	TR,2SB1 TR,KTC3 TR,2SB1	436(R) 199GR 370E		C3 C4 C21 C22 C25	87-012-368-080 87-012-368-080 87-016-658-090 87-016-658-090 87-016-300-080	C-CAP, CAP,E CAP,E	S 0.1-50 ZF S 0.1-50 ZF 4700-35 M 4700-35 M 22-100 SME
	87-A30-087-080 87-A30-086-040 87-A30-076-080 87-A30-107-070 87-A30-074-080	C-TR,CS C-TR,2S C-TR,CM	D1306E C3052F BT5401		C26 C27 C28 C31 C32	87-016-300-080 87-016-300-080 87-016-300-080 87-010-263-080 87-010-197-080	CAP,E CAP,E CAP, E	22-100 SME 22-100 SME 22-100 SME LECT 100-10V HIP 0.01 DM
	87-A30-190-080 87-A30-105-080 87-026-610-080 87-A30-106-080 87-A30-276-040	TR,CC55 C-TR,RT TR,KTC3 C-TR,CM	51 1P441C 198GR BT5551		C33 C34 C35 C36 C38	87-010-263-080 87-010-247-080 87-010-406-080 87-010-381-080 87-010-393-080	CAP, E CAP, E CAP, E	100-10 M LECT 100-50V LECT 22-50V LECT 330-16V LECT 100-35V
	87-A30-063-080 87-026-609-080 87-A30-186-010 87-A30-075-080	C-TR, KR TR, KTA1 FET, 2SK C-TR, 2S	A104S 266GR 3053		C39 C40 C60 C80 C81	87-010-393-080 87-010-190-080 87-010-403-080 87-010-401-080 87-010-374-080	S CHIP CAP, E CAP, E	LECT 100-35V F 0.01 LECT 3.3-50V LECT 1-50V LECT 47-10V
	87-A30-329-080 87-A30-522-010 87-A30-318-080 89-327-143-080 87-A30-072-080	TR,2SB1 TR,CSA9 TR,2SC2 C-TR,RT	549 52K 714O 1P 144C		C82 C104 C105 C111 C112	87-010-260-080 87-010-196-080 87-010-196-080 87-010-401-080 87-010-401-080	CHIP C CHIP C CAP, E	LECT 47-25V APACITOR,0.1-25 APACITOR,0.1-25 LECT 1-50V LECT 1-50V
	87-A30-234-080 87-A30-523-010 89-503-602-080 87-A30-269-040 87-A30-097-010 87-A30-098-010	TR,2SD2 C-FET,2 C-FET,2 TR,FN10	562 SK360E SJ461-T1 16		C115 C116 C121 C122 C151	87-010-401-080 87-010-401-080 87-010-404-080 87-010-404-080 87-010-405-080	CAP, E CAP, E CAP, E	LECT 1-50V LECT 1-50V LECT 4.7-50 LECT 4.7-50 LECT 10-50V
	87-A30-073-080 87-026-463-080 87-A30-468-080 87-A30-484-080 87-A30-489-080	C-TR,RT TR,2SA9 C-TR,KR C-TR,KR	1N141C 33S C102S-RTK A102S		C160 C163 C171 C172 C173	87-012-140-080 87-010-196-080 87-012-368-080 87-012-368-080 87-012-368-080	CHIP C C-CAP, C-CAP,	S 470P-50J CH APACITOR,0.1-25 S 0.1-50 F S 0.1-50 F S 0.1-50 F
DIODE	87-A30-107-070		MBT5401		C174 C175 C176 C177 C178	87-012-368-080 87-A11-572-080 87-A11-572-080 87-010-197-080 87-010-197-080	C-CAP, C-CAP, CAP, C	S 0.1-50 F S 0.015-50 K B S 0.015-50 K B HIP 0.01 DM HIP 0.01 DM
	87-A40-673-090 87-020-465-080 87-A40-438-080 87-017-654-060 87-A40-736-080	DIODE,1 ZENER,M DIODE,G	SS133		C301 C302 C303 C304 C305	87-010-318-080 87-010-318-080 87-012-157-080 87-012-157-080 87-012-157-080	C-CAP, C-CAP, C-CAP, C-CAP,	S 47P-50 CH S 47P-50 CH S 330P-50 CH S 330P-50 CH S 330P-50 CH
	87-A40-393-090 87-A40-553-080 87-A40-781-080 87-070-274-080	DIODE,1: ZENER,U	N5402GW (F20) N4003 LES Z36BSA N4003 SEM		C306 C307 C311 C312	87-012-157-080 87-010-196-080 87-010-198-080 87-010-198-080	CHIP C	S 330P-50 CH APACITOR,0.1-25 HIP 0.022 HIP 0.022

REF. NO		KANRI DESCRIPTION NO.	REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
C313 C314 C315 C316 C317	87-010-180-080 87-010-180-080 87-010-178-080 87-010-178-080 87-A10-201-080	C-CER 1500P C-CER 1500P CHIP CAP 1000P CHIP CAP 1000P C-CAP,S 0.33-16 KB	C430 C431 C432 C433 C434	87-A10-201-080 87-010-971-080 87-012-349-080 87-A11-183-080 87-A11-182-080	C-CAP,S C-CAP,S C-CAP,S C-CAP,S	0.33-16 KB 4700P-50 JB 1000P-50 CH 0.12-16 JB 0.27-16 JB
C318 C319 C320 C321 C322	87-A10-201-080 87-012-141-080 87-012-141-080 87-012-141-080 87-012-141-080	C-CAP,S 0.33-16 KB CHIP-CAPACITOR,0.22-16F CHIP-CAPACITOR,0.22-16F CHIP-CAPACITOR,0.22-16F CHIP-CAPACITOR,0.22-16F	C435 C436 C437 C438 C439	87-A11-182-080 87-A11-183-080 87-010-971-080 87-012-349-080 87-010-805-080	C-CAP,S C-CAP,S C-CAP,S	0.27-16 JB 0.12-16 JB 4700P-50 JB 1000P-50 J CH GRM 1-16 ZF
C324 C325 C327 C328 C332	87-010-260-080 87-010-370-080 87-010-404-080 87-010-404-080 87-010-196-080	CAP, ELECT 47-25V CAP,E 330-6.3 SME CAP, ELECT 4.7-50V CAP, ELECT 4.7-50V CHIP CAPACITOR,0.1-25		87-010-401-080 87-A10-799-080 87-A10-802-080 87-A10-229-080 87-016-460-080	C-CAP,S C-CAP,S C-CAP,S	-50 M 5600P-16 JB 0.047-16 JB 0.68-10 K W5R 0.22-16 KB
C335 C336 C337 C339 C340	87-010-401-080 87-010-401-080 87-010-196-080 87-010-196-080 87-010-196-080	CAP, ELECT 1-50V CAP, ELECT 1-50V CHIP CAPACITOR,0.1-25 CHIP CAPACITOR,0.1-25 CHIP CAPACITOR,0.1-25	C445 C446 C447 C448 C449	87-016-460-080 87-010-404-080 87-010-404-080 87-016-460-080 87-016-460-080	CAP,E 4 CAP,E 4 CAP,E 0	
C351 C352 C354 C355 C356	87-012-140-080 87-012-140-080 87-010-175-080 87-012-349-080 87-010-260-080	CAP 470P CAP 470P CAP 560P C-CAP,S 1000P-50 CH CAP, ELECT 47-25V	C450 C451 C452 C453 C454	87-016-081-080 87-A10-802-080 87-A10-802-080 87-016-081-080 87-016-081-080	C-CAP,S C-CAP,S C-CAP,S	0.1-16 KR GRM 0.047-16 JB CM 0.047-16 JB CM 0.1-16 KR GRM 0.1-16 KR GRM
C357 C358 C359 C360 C370	87-010-197-080 87-010-183-080 87-010-183-080 87-010-183-080 87-010-196-080	CAP, CHIP 0.01 DM C-CAP,S 2700P-50 B C-CAP,S 2700P-50 B C-CAP,S 2700P-50 B CHIP CAPACITOR,0.1-25	C455 C456 C457 C461 C463	87-A10-801-080 87-A10-801-080 87-016-081-080 87-010-196-080 87-010-196-080	C-CAP,S C-CAP,S C-CAP,S	0.022-16 JB CM 0.022-16 JB CM 0.1-16 KR GRM 0.1-25 ZF C2012 0.1-25 ZF C2012
C371 C372 C373 C374 C375	87-010-175-080 87-010-175-080 87-010-179-080 87-010-179-080 87-010-545-080	CAP 560P CAP 560P CAP,CHIP S B1200P CAP,CHIP S B1200P CAP, ELECT 0.22-50V		87-A10-201-080 87-A10-060-080 87-012-140-080 87-012-140-080 87-012-140-080	C-CAP,S C-CAP,S C-CAP,S	0.33-16 K B 0.18-16 K B 470P-50 J CH 470P-50 J CH 470P-50 J CH
C376 C378 C381 C382 C383	87-010-545-080 87-010-196-080 87-010-197-080 87-010-318-080 87-010-197-080	CAP, ELECT 0.22-50V CHIP CAPACITOR,0.1-25 CAP, CHIP 0.01 DM C-CAP,S 47P-50 CH CAP, CHIP 0.01 DM	C475 C476 C477 C478 C479	87-012-140-080 87-012-140-080 87-012-140-080 87-010-265-080 87-010-179-080	C-CAP,S C-CAP,S CAP,E 3	470P-50 J CH 470P-50 J CH 470P-50 J CH 3-16 M 1200P-50 KB GRM
C384 C385 C386 C388 C401	87-010-402-080 87-010-184-080 87-010-196-080 87-012-156-080 87-010-176-080	CAP, ELECT 2.2-50V CHIP CAPACITOR 3300P(K) CHIP CAPACITOR,0.1-25 C-CAP,S 220P-50 CH C-CAP,S 680P-50 J SL	C480 C481 C482 C483 C489	87-010-179-080 87-010-179-080 87-010-179-080 87-010-265-080 87-010-402-080	C-CAP,S C-CAP,S CAP,E 3	
C402 C403 C404 C405 C406	87-010-176-080 87-010-958-080 87-010-958-080 87-010-958-080 87-010-958-080	C-CAP,S 680P-50 J SL C-CAP,S 0.01-25 JB C-CAP,S 0.01-25 JB C-CAP,S 0.01-25 JB C-CAP,S 0.01-25 JB	C491 C492 C531 C532 C533	87-010-402-080 87-010-402-080 87-010-560-080 87-010-196-080 87-010-196-080	CAP,E 2 CAP,E 1 CHIP CA	
C407 C408 C409 C410 C411	87-010-401-080 87-010-401-080 87-010-196-080 87-010-384-080 87-010-401-080	CAP,E 1-50 M CAP,E 1-50 M C-CAP,S 0.1-25 ZF CAP,E 100-25 M CAP,E 1-50 M 11L SME	C534 C535 C536 C541 C600	87-012-156-080 87-010-178-080 87-010-196-080 87-010-178-080 87-018-123-080	CHIP CA CHIP CA CHIP CA	PACITOR,0.1-25
C412 C413 C414 C415 C416	87-010-401-080 87-010-401-080 87-010-494-080 87-010-492-080 87-010-492-080	CAP,E 1-50 M 11L SME CAP,E 1-50 M 11L SME CAP,E 1-50 M 5L SRE CAP,E 0.33-50 M 5L CAP,E 0.33-50 M 5L	C603 C604 C605 C606 C611	87-010-318-080 87-010-318-080 87-010-318-080 87-010-318-080 87-010-956-080	C-CAP,S C-CAP,S C-CAP,S	47P-50 CH 47P-50 CH 47P-50 CH 47P-50 CH P,S 0.068-25B
C417 C418 C419 C420 C421	87-010-221-080 87-A10-891-080 87-A10-800-080 87-010-374-080 87-010-196-080	CAP,E 470-10 M SME CAP,E 4.7-25 SME (K) C-CAP,S 6800P-16 JB CM CAP,E 47-10 SME C-CAP,S 0.1-25 ZF	C612 C613 C614 C616 C617	87-010-369-080 87-010-197-080 87-016-669-080 87-010-180-080 87-010-198-080	CAP, CH C-CAP,S C-CER 1	0.033-25 KB IP 0.01 DM 0.1-25 KB 500P IP 0.022
C422 C424 C425 C428 C429	87-A10-804-080 87-010-374-080 87-010-196-080 87-012-156-080 87-010-545-080	C-CAP,S 0.1-25 JB CAP,E 47-10 SME C-CAP,S 0.1-25 ZF C-CAP,S 220P-50 J CH CAP,E 0.22-50 M	C618 C619 C620 C621 C623	87-010-401-080 87-010-263-080 87-016-669-080 87-010-197-080 87-010-401-080	CAP, EL C-CAP,S CAP, CH	ECT 1-50V ECT 100-10V 0.1-25 KB IP 0.01 DM ECT 1-50V

REF. NO	. PART NO.	KANRI NO.	DESCRIPTION	REF. NO		(ANRI DESCRIPTI	ON
C624 C626 C627 C628 C629	87-010-401-080 87-010-992-080 87-010-400-080 87-010-400-080 87-010-992-080	CAP, EL C-CAP,S CAP, EL CAP, EL C-CAP,S	ECT 1-50V 0.047-25 B ECT 0.47-50V ECT 0.47-50V 0.047-25 B		87-010-971-080 87-010-197-080 87-010-148-080 87-010-197-080 87-010-197-080	C-CAP,S 4700P-50 C-CAP,S P-5C942 C-CAP,S 4P-50 C C-CAP,S 0.01-25 C-CAP,S 0.01-25	CH KB
C630 C631 C632 C634 C635	87-010-383-080 87-010-185-080 87-010-185-080 87-010-196-080 87-A10-307-080	CAP, EL C-CAP,S C-CAP,S CHIP CA CAP,M 0	ECT 33-25V 3900P-50 B 3900P-50 B PACITOR,0.1-25 .1-50 J	C954 C956 C959 C962 C963	87-010-400-080 87-010-263-080 87-010-196-080 87-010-401-080 87-015-785-080	CAP,E 0.47-50M CAP,E 100-10 M CHIP CAPACITOR,O CAP,E 1-50 SME CHIP CAPACITOR,	
C636 C637 C638 C639 C641	87-A10-307-080 87-A10-307-080 87-A10-307-080 87-010-405-080 87-010-401-080	CAP,M 0 CAP,M 0 CAP,M 0 CAP, EL	.1-50 J .1-50 J .1-50 J ECT 10-50V ECT 1-50V	C964 C971 C972 C973 C974	87-010-854-080 87-010-381-080 87-010-404-080 87-010-197-080 87-010-197-080	C-CAP,S 560P-50 CAP, ELECT 330-1 CAP, ELECT 4.7-5 CAP, CHIP 0.01 D CAP, CHIP 0.01 D	OV M
C642 C643 C644 C671 C672	87-010-401-080 87-010-196-080 87-010-401-080 87-010-322-080 87-010-322-080		ECT 1-50V PACITOR,0.1-25 ECT 1-50V 100P-50 CH 100P-50 CH		87-010-322-080 87-010-260-080 87-010-196-080 87-010-197-080 87-010-197-080	C-CAP,S 100P-50 CAP, ELECT 47-25 CHIP CAPACITOR,O CAP, CHIP 0.01 D CAP, CHIP 0.01 D	V .1-25 M
C673 C675 C679 C680 C771	87-010-197-080 87-010-196-080 87-010-196-080 87-010-197-080 87-010-263-080	CAP, CH CHIP CA CHIP CA CAP, CH	IP 0.01 DM PACITOR,0.1-25 PACITOR,0.1-25 IP 0.01 DM ECT 100-10V	C987 C989 C991 C992 C993	87-010-197-080 87-010-197-080 87-010-312-080 87-010-312-080 87-010-178-080	CAP, CHIP 0.01 D C-CAP,S 0.01-25 C-CAP,S 15P-50 C C-CAP,S 15P-50 C CHIP CAP 1000P	KB 'H
C772 C773 C774 C782 C783	87-010-197-080 87-010-184-080 87-010-184-080 87-010-197-080 87-010-197-080	CAP, CH CHIP CA CHIP CA CAP, CH CAP, CH	IP 0.01 DM PACITOR 3300P(K) PACITOR 3300P(K) IP 0.01 DM IP 0.01 DM	C995 C997 C998 C999 CF831	87-010-178-080 87-010-196-080 87-010-260-080 87-A11-155-080 87-008-261-010	CHIP CAP 1000P CHIP CAPACITOR, 0 CAP, ELECT 47-25 CAP,TC U 0.01-16 FLTR, CF SFE10.7	V ZF
C784 C785 C786 C788 C789	87-010-197-080 87-010-197-080 87-010-197-080 87-010-149-080 87-012-365-080	CAP, CH CAP, CH CAP, CH C-CAP,S C-CAP,S	IP 0.01 DM IP 0.01 DM IP 0.01 DM 5P-50 CH 0.027-25VBK	CF832 CN1 CN91 CN92 CN101	87-008-261-010 87-A60-996-010 8A-NHP-640-010 87-A60-619-010 87-A60-996-010	CF,SFE10.7MA5 CONN,13P V BLK T CONN ASSY,2P(FAN CONN,2P V 2MM JM CONN,13P V BLK T) ANHP-500 T
C790 C791 C792 C793 C795	87-012-365-080 87-010-196-080 87-010-197-080 87-010-404-080 87-010-197-080	C-CAP,S CHIP CA CAP, CH CAP, EL CAP, CH	0.027-25VBK PACITOR,0.1-25 IP 0.01 DM ECT 4.7-50V IP 0.01 DM	CN301 CN351 CN601 CN602 CN605	87-A60-620-010 87-A60-625-010 87-099-719-010 87-A60-131-010 87-099-568-010	CONN, 3P V 2MM JM CONN, 8P V 2MM JM CONN, 30P TYK-B(X CONN, 6P V FE CONN, 11P TUC-P11	T :)
C796 C797 C798 C799 C800	87-010-197-080 87-010-405-080 87-010-197-080 87-010-407-080 87-012-369-080	CAP, EL CAP, CH CAP, EL	IP 0.01 DM ECT 10-50V IP 0.01 DM ECT 33-50V 0.047-50F	CN606 CNA1 CNA2 D951 FB301	87-099-566-010 8A-NF8-653-010 8A-NF3-640-110 87-A40-618-080 87-008-372-080	CONN,7P TUC-P7P- CONN ASSY,9P TIE CONN ASSY,3P (VM VARI-CAP,SCV 348 FILTER, EMI BLOI	D-A(480) I) ANF-3 I (S/T)
C801 C802 C803 C804 C807	87-010-403-080 87-012-369-080 87-010-198-080 87-010-263-080 87-010-400-080	C-CAP,S CAP, CH CAP, EL	ECT 3.3-50V 0.047-50F IP 0.022 ECT 100-10V ECT 0.47-50V	FFC302 FFE831 J102 J103 J431	88-906-481-110 A8-8ZA-190-030 87-A60-238-010 87-A60-483-010 87-A61-069-010	FF-CABLE,6P 1.25 8ZA-1 FEEUNM TERMINAL,SP 4P (JACK,DIA6.3 BLK JACK,PIN 6P R/W,	MSC) ST W/S KM
C808 C809 C810 C811 C812	87-010-401-080 87-010-401-080 87-010-196-080 87-010-403-080 87-010-403-080	CAP, EL CHIP CA CAP, EL	ECT 1-50V ECT 1-50V PACITOR,0.1-25 ECT 3.3-50V ECT 3.3-50V	J601 J831 J940 JW991 L101	87-A60-885-010 87-A60-202-010 87-A60-633-010 87-003-216-080 87-A50-610-010	JACK,PIN 6P R/W TERMINAL,ANT 4P CONN, 2P H 2.5MM F-BEAD,-3.6-5 BL COIL,1UH K(MDEC)	MSP-154V-02 I JMT .01RN1-A62T5
C814 C815 C816 C819 C820	87-010-197-080 87-010-400-080 87-010-400-080 87-010-179-080 87-010-179-080	CAP, EL CAP, EL CAP,CHI	IP 0.01 DM ECT 0.47-50V ECT 0.47-50V P S B1200P P S B1200P	L102 L301 L302 L351 L801	87-A50-610-010 87-A50-049-010 87-A50-049-010 87-007-342-010 87-A50-608-010	COIL,1UH K(MDEC) COIL,TRAP 85K(CC COIL,TRAP 85K(CC COIL,OSC 85K BIA COIL,FM DET-N(TC	I) I) S
C821 C823 C824 C825 C849	87-010-405-080 87-010-177-080 87-010-404-080 87-010-596-080 87-010-196-080	C-CAP,S CAP, EL CAP,S 0	ECT 10-50V 820P-50 J SL ECT 4.7-50V .047-16 0.1-25 ZF	L802 L811 L821 L822 L832	87-A91-551-010 87-005-847-080 87-A50-209-010 87-A50-209-010 87-005-847-080	FLTR,PCFJZH-450 COIL,2.2UH(CECS) COIL,1POLE MPX(M COIL,1POLE MPX(M COIL,2.2UH(CECS)	IIT) IIT)
C870 C940 C941 C943 C945	87-018-131-080 87-010-197-080 87-010-314-080 87-010-197-080 87-010-197-080	C-CAP,S C-CAP,S C-CAP,S	U 1000P-50 KB 0.01-25 KB 22P-50 CH 0.01-25 KB 0.01-25 KB	L941 L942 L943 L944 L952	87-A50-022-010 87-A50-550-010 87-A50-522-080 87-A50-159-010 87-A50-430-010	COIL,ANT SW (COI COIL,OSC SW-2N (COIL,1MH K CEC COIL,10MH K C2B COIL,ANT MW (3BS	COI)

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION	REF. NO	. PART NO.	KANRI NO.	DESCRIPTION
L953 R25 R117 R118 R161	87-A50-431-010 87-A00-261-080 87-012-142-080 87-012-142-080 87-A00-441-050	COIL,OSC RES,M/F C-CAP,S C-CAP,S	C MW (3BSW) 0.56-1WJ 0.33-16 ZF 0.33-16 ZF 1/2W J RP	C807 C809 C810 C811 C812	87-010-197-080 87-012-155-080 87-010-264-040 87-010-244-040 87-016-044-040	C-CAP,S C-CAP,S CAP,E 10 CAP,E 22	0.01-25 KB 180P-50 J CH 00-10 M 5L SRE 2-16 M 5L SRE 00-16 M 5L MA
R162 R163 R164 R790 R991	87-A00-441-050 87-A00-441-050 87-A00-441-050 87-010-197-080 87-010-322-080	RES,270- RES,270- CAP, CHI	-1/2W J RP -1/2W J RP -1/2W J RP -1/2W J RP 	C821 C833 C901 C902 C903	87-010-196-080 87-010-322-080 87-012-157-080 87-010-176-080 87-010-176-080	C-CAP,S C-CAP,S C-CAP,S	0.1-25 ZF 100P-50 J CH 330P-50 CH 680P-50 SL 680P-50 SL
R993 R995 SFR301 SFR302 SFR303	87-010-322-080 87-010-322-080 87-024-355-080 87-024-355-080 87-024-355-080		100P-50 CH DIA6 H DIA6 H	C904 C905 C906 C907 C908	87-010-176-080 87-010-176-080 87-010-176-080 87-010-176-080 87-010-176-080	C-CAP,S C-CAP,S C-CAP,S	680P-50 SL 680P-50 SL 680P-50 SL 680P-50 SL 680P-50 SL
SFR304 SFR305 SFR306 SFR351 SFR352	87-024-355-080 87-024-356-080 87-024-356-080 87-024-356-080 87-024-356-080	SFR,47K SFR,47K	DIA6 H DIA6 H DIA6 H	C909 C910 C911 C912 C913	87-010-176-080 87-010-176-080 87-010-176-080 87-010-176-080 87-010-176-080	C-CAP,S C-CAP,S C-CAP,S	680P-50 SL 680P-50 SL 680P-50 SL 680P-50 SL 680P-50 SL
TC941 TC943 WH1 X991	87-011-254-080 87-011-253-080 87-A90-510-010 87-A70-061-010	TRIMMER, HLDR,WIF	CER 20P 4.0X4.5 ECR CER 30P 4.0X4.5 ECRLA RE 2.5-9P L 4.500MHZ CSA-309	C914 CN101 CN102 CN103 CN601	87-012-145-080 87-099-720-010 87-A60-055-010 87-099-750-010 87-A60-062-010	CONN, 301 CONN, 131 CONN, 151	TP S 270P CH P TYK-B(P) P V 9604S-13C P V 9604SC P V 9604S-05C
DISPLAY C	.В			CN701	87-099-750-010		V 9604SC
C103 C104 C105 C106	87-010-196-080 87-010-313-080 87-010-322-080 87-012-145-080	CAP, CHI C-CAP,S	PACITOR,0.1-25 IP 18P 100P-50 CH IP S 270P CH	FFC102 FFC104 FFC601 FFC701	88-914-481-110 88-915-161-110 88-905-081-110 88-915-161-110	FF-CABLE FF-CABLE	2,14P 1.25 480MM 2,15P 1.25 2,5P 1.25 2,15P 1.25
C107 C108 C109 C110	87-012-157-080 87-015-681-040 87-010-401-040 87-010-196-080	E/CAP 10 CAP,E 1-		FL101 JR102 JW315 JW316 L101	8A-NF3-613-010 83-XM1-617-080 87-A90-896-080 87-A90-896-080 87-A50-333-010	C-COIL, F-BEAD, F-BEAD,	PGK-ANF3 BK2125HM601 035600STY7 035600STY7 D 9.43MHZ
C112 C113	87-016-460-080 87-A10-189-040		0.22-16 B	L801	87-A50-093-010		OCK OSC 5.76MHZ
C114 C115 C116 C117 C118	87-010-196-080 87-010-198-080 87-010-493-040 87-010-498-040 87-010-194-080	CAP, CHI CAP,E 0. CAP,E 10	47-50 GAS	L802 CD KEY C. CN301	87-003-098-080 B 87-A60-079-010		PUH K LAL02
C119 C120 C121 C122	87-A10-797-040 87-015-699-040 87-015-699-040 87-010-197-080	CAP,E 47 CAP,E 10 CAP,E 10	7-35 M 5L SRM 0-50 7L	FFC302	88-908-381-110 87-A40-380-180 87-A40-380-180 87-A40-380-180	FF-CABLE LED,SEL6 LED,SEL6	E,8P 1.25
C123 C125 C128 C129	87-010-196-080 87-010-196-080 87-010-178-080 87-010-194-080	CHIP CAR CHIP CAR CHIP CAR CAP, CHI	PACITOR, 0.1-25 PACITOR, 0.1-25 PACITOR 0.1-25 PACITOR 0.047	LED314 LED315 S311 S312 S313	87-A40-380-180 87-A40-380-180 87-A90-095-080 87-A90-095-080 87-A90-095-080	LED, SEL6 SW, TACT SW, TACT	5510C-TP5 GRN 5510C-TP5 GRN EVQ11G04M EVQ11G04M EVQ11G04M
C131 C132	87-A10-189-040 87-A10-189-040	CAP,E 22 CAP,E 22		S314 S315	87-A90-095-080 87-A90-095-080		EVQ11G04M EVQ11G04M
C151 C192 C196 C197	87-010-194-080 87-015-785-080 87-010-194-080 87-010-194-080	CHIP CAL		S316 S317	87-A90-095-080 87-A90-095-080		EVQ11G04M EVQ11G04M
C213	87-A10-189-040	CAP,E 22		CONTROL C			
C301 C303 C304 C305 C306	87-010-318-080 87-016-460-080 87-016-460-080 87-010-196-080 87-010-196-080	C-CAP,S C-CAP,S CHIP CAE	47P-50 CH 0.22-16 B 0.22-16 B PACITOR,0.1-25 PACITOR,0.1-25	C401 C407 C410 C417 C423	87-010-196-080 87-010-322-080 87-010-196-080 87-010-322-080 87-010-196-080	C-CAP,S CHIP CAI C-CAP,S	PACITOR, 0.1-25 100P-50 CH PACITOR, 0.1-25 100P-50 CH PACITOR, 0.1-25
C310 C701 C801 C802 C803	87-010-067-040 87-010-981-040 87-012-156-080 87-010-176-080 87-010-187-080	CAP,E 22 C-CAP,S C-CAP,S	1-50 5L 2-35 5L SRE 220P-50 J CH GRM 680P-50 J SL 5600P-50 KB	C424 C501 C502 C531 C532	87-010-196-080 87-010-178-080 87-012-156-080 87-010-196-080 87-010-196-080	CHIP CAI C-CAP,S CHIP CAI	PACITOR, 0.1-25 0 1000P 220P-50 CH PACITOR, 0.1-25 PACITOR, 0.1-25
C804 C805 C806	87-010-213-080 87-010-197-080 87-010-071-040	C-CAP,S	0.015-25 KB 0.01-25 KB -50 M 5L SRE	CN104 CN302 L601	87-099-750-010 87-A60-059-010 87-003-098-080	CONN,081	V 9604SC V 9604S-08C CUH K LAL02


REF. NO). PART NO.	KANRI NO.	DESCRIPTION		REF. NC). PART NO.	KANRI NO.	DESCRIPTION
LED101	87-A40-317-080		2-342VCT31 RED		VOLUME C.	В		
LED421	87-A40-831-010		JU1E10CXM-LF70		91.61	00 010 100 000	a	n 1000n
LED422 LED440	87-A40-831-010 87-A40-380-180		U1E10CXM-LF70 6510C-TP5 GRN	BLOE-DEL	C161 C162	87-010-178-080 87-012-156-080		AP 1000P S 220P-50 CH
LED110	87-A40-380-180		6510C-TP5 GRN		S511	87-A90-095-080		Γ EVQ11G04M
					S512	87-A90-095-080		Γ EVQ11G04M
LED442 LED443	87-A40-380-180 87-A40-380-180		6510C-TP5 GRN 6510C-TP5 GRN		S513	87-A90-095-080	SW,TACT	Γ EVQ11G04M
LED443	87-A40-380-180		6510C-TP5 GRN		S514	87-A90-095-080	SW.TACT	Γ EVQ11G04M
LED445	87-A40-380-180	LED, SEL	6510C-TP5 GRN		S515	87-A90-095-080	SW, TACT	r EVQ11G04M
LED446	87-A40-380-180	LED, SEL	6510C-TP5 GRN		SW101	87-A91-740-010	SW,RTRY	Y EC12E24308-30MM
LED447	87-A40-380-180	LED. SEI	6510C-TP5 GRN					
LED448	87-A40-380-180		6510C-TP5 GRN		MIC C.B			
LED449	87-A40-380-180		6510C-TP5 GRN					
LED451 LED452	87-A40-809-040 87-A40-809-040	,	-307KK PGRN -307KK PGRN		C601 C602	87-010-196-080 87-010-186-080		APACITOR,0.1-25 IP 4700P
HHD 132	07 A10 005 010	םםם, בוב	307KK 10KV		C603	87-010-112-040		
LED453	87-A40-809-040		-307KK PGRN		C604	87-010-405-040		
LED454 LED455	87-A40-809-040 87-A40-809-040		-307KK PGRN -307KK PGRN		C605	87-010-546-040	CAP,E C	0.33-50
LED455	87-A40-809-040		-307KK PGRN		C606	87-010-320-080	CHIP CA	AP 68P
LED461	87-A40-317-080		R-342VCT31 RED		C608	87-012-157-080	,	330P-50 CH
T ED 460	07 7/0 217 000	TED CID	משת 240זזמשמזו 240		C621	87-010-178-080		AP 1000P
LED462 LED463	87-A40-317-080 87-A40-317-080		R-342VCT31 RED R-342VCT31 RED		CN602 J601	87-A60-082-010 87-A61-242-010		5P H 9604S-05F .3 BLK MONO W/SW V KM
LED464	87-A40-317-080		R-342VCT31 RED					
LED465	87-A40-317-080	,	R-342VCT31 RED		J602	87-A61-242-010		.3 BLK MONO W/SW V KM
LED521	87-A40-678-010	LED, SEL	LU1E10CXM BLUE-	DEF	L601	87-003-098-080	COIL,2.	. 2UH
LED522	87-A40-678-010	LED, SEL	U1E10CXM BLUE-	DEF				
S201	87-A90-095-080		EVQ11G04M		AMP 1F C.	В		
S202 S203	87-A90-095-080 87-A90-095-080		EVQ11G04M EVQ11G04M		C101	07 010 102 000	מאח מנוז	ID 2700D E0
S203 S204	87-A90-095-080		EVQ11G04M		C101	87-010-183-080 87-010-183-080		IP 2700P-50 IP 2700P-50
			-		C103	87-010-405-080	CAP, EI	LECT 10-50V
S205	87-A90-095-080		EVQ11G04M		C104	87-010-405-080		LECT 10-50V
S206 S207	87-A90-095-080 87-A90-095-080		EVQ11G04M EVQ11G04M		C107	87-010-403-080	CAP, EL	LECT 3.3-50V
S208	87-A90-095-080		EVQ11G04M		C108	87-010-403-080	CAP, EI	LECT 3.3-50V
S211	87-A90-095-080	SW,TACT	EVQ11G04M		C111	87-010-322-080		3 100P-50 CH
S212	87-A90-095-080	¢₩ ሞአ <i>ር</i> ጥ	EVQ11G04M		C112 C113	87-010-322-080 87-A10-812-080	,	S 100P-50 CH S 220P-200 J CH
S212	87-A90-095-080		EVQ11G01M		C114	87-A10-812-080		3 220P-200 J CH
S214	87-A90-095-080		EVQ11G04M					
S215 S216	87-A90-095-080 87-A90-095-080	,	EVQ11G04M EVQ11G04M		C119 C120	87-010-197-080 87-010-197-080		HIP 0.01 DM HIP 0.01 DM
5210	07-A30-033-000	SW, IACI	. EVQIIGUIM		C121	87-010-157-080		LECT 47-25V
S217	87-A90-095-080		EVQ11G04M		C122	87-010-260-080		LECT 47-25V
S221 S222	87-A90-095-080 87-A90-095-080		EVQ11G04M EVQ11G04M		C173	87-010-186-080	CAP, CHI	IP 4700P
S222 S223	87-A90-095-080	,	EVQ11G04M		C174	87-010-186-080	CAP, CHI	IP 4700P
S224	87-A90-095-080	SW, TACT	EVQ11G04M		C205	87-010-187-080		IP S5600P
S225	87-A90-095-080	CM TACT	EVQ11G04M		C206 C207	87-010-187-080 87-010-403-080	,	IP S5600P LECT 3.3-50V
S225	87-A90-095-080	,	EVQ11G04M		C207	87-010-403-080		LECT 3.3-50V
S227	87-A90-095-080	SW, TACT	EVQ11G04M					
S228 S229	87-A90-095-080		EVQ11G04M EVQ11G04M		C209 C210	87-010-184-080 87-010-184-080		APACITOR 3300P(K) APACITOR 3300P(K)
3447	87-A90-095-080	SW,IACI	. ₽∧ÕTTG∩4M		C210 C211	87-010-184-080 87-010-401-080		LECT 1-50V
S230	87-A90-095-080		EVQ11G04M		C212	87-010-401-080	CAP, EI	LECT 1-50V
S231 S232	87-A90-095-080 87-A90-095-080		EVQ11G04M EVQ11G04M		C215	87-012-156-080	C-CAP,S	3 220P-50 CH
S232 S233	87-A90-095-080		EVQIIGU4M EVO11G04M		C216	87-012-156-080	C-CAP.S	S 220P-50 CH
S234	87-A90-095-080	,	EVQ11G04M		C217	87-010-260-080	CAP, EI	LECT 47-25V
0041	07 300 005 000	Ott 73.00	B 1011004:		C218	87-010-260-080		LECT 47-25V
S241 S242	87-A90-095-080 87-A90-095-080	,	EVQ11G04M EVQ11G04M		C221 C222	87-016-100-080 87-016-100-080	,	LECT 10-50 M BP SME LECT 10-50 M BP SME
S243	87-A90-095-080	SW, TACT	EVQ11G04M				J / EL	
S244	87-A90-095-080		EVQ11G04M		C223	87-010-197-080		HIP 0.01 DM
S245	87-A90-095-080	SW,TACI	EVQ11G04M		C224 C249	87-010-197-080 87-012-368-080	,	HIP 0.01 DM S 0.1-50 F
S246	87-A90-095-080	SW,TACT	EVQ11G04M		C251	87-010-993-080	,	3 0.056-25 B
S247	87-A90-095-080		EVQ11G04M		C252	87-010-196-080		APACITOR,0.1-25
S248 S249	87-A90-095-080 87-A90-095-080		EVQ11G04M EVQ11G04M		C253	87-010-196-080	CHID CA	APACITOR, 0.1-25
S249 S250	87-A90-095-080		EVQ11G04M		C253	87-010-196-080		3 0.056-25 B
			-		C255	87-010-190-080	S CHIP	F 0.01
S251	87-A90-095-080		EVQ11G04M EVQ11G04M		C256 C265	87-010-190-080		
S252 S253	87-A90-095-080 87-A90-095-080		EVQ11G04M EVQ11G04M		C205	87-010-260-080	CAP,E 4	1 - Z D V
SW501	87-A91-739-010		EC12E12404-25	MM RT	C402	87-010-196-080		APACITOR,0.1-25
					C413	87-A10-119-080	CAP,E 1	10-100 REA


REF. NO.	PART NO.	KANRI NO.	DESCRIPTION		REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
C414 C495 C496 CNA101 CNA103	87-A10-120-080 87-A10-812-080 87-A10-812-080 8A-NF8-652-010 8A-NF8-656-010	CAP,E 2: C-CAP,S: C-CAP,S: CONN AS:	2-100 REA 220P-200 J 220P-200 J SY,7P TID-A(480) SY,5P TID-A(400)		CN1 CN2 CN91 CN101 CN102	87-A60-619-010 87-A60-619-010 87-099-043-010 87-A61-109-010 87-A60-135-010	CONN, 2P CONN, 2P CONN, 2P	V 2MM JMT V 2MM JMT V WHT EH V TID-A P V FE
CON101 CON102 CON103 CON104 J201	87-A61-011-010 87-A61-011-010 87-A60-058-010 87-A61-142-010 87-A61-158-010	CONN, 131	P H BLK TAC-L13P-A3 P H BLK TAC-L13P-A3 P V 9604S-10C V THL-P07-A1 V 2P R/W/BL H (SEPA)K	M	J101 L151 L152 L251 R131	87-A61-438-010 87-A50-610-010 87-A50-610-010 87-A50-610-010 87-A00-764-010	COIL, 11 COIL, 11 COIL, 11	IN 3P O/W/R UH K (MDEC) UH K (MDEC) UH K (MDEC) 0.22-3W J
JW138 JW944 L251 L252 R161	87-A90-896-080 87-A90-896-080 87-A50-610-010 87-A50-610-010 87-A00-669-080	F-BEAD, COIL,1UI COIL,1UI	035600STY7 035600STY7 H K(MDEC) H K(MDEC) 0.22-2W JRA		R132 R171 R172 R218 R278	87-A00-764-010 87-A00-764-010 87-A00-764-010 87-A00-262-080 87-A00-262-080	RES,M/F RES,M/F RES,M/F	0.22-3W J 0.22-3W J 0.22-3W J 0.15-2W J 0.15-2W J
R162 R163 R164 R165 R166	87-A00-669-080 87-A00-669-080 87-A00-669-080 87-A00-669-080 87-A00-669-080	RES,M/F RES,M/F RES,M/F	0.22-2W J 0.22-2W J 0.22-2W J 0.22-2W J 0.22-2W J		TH 201	87-A91-042-080		100K 55001
R167 R168 R231 R232 R243	87-A00-669-080 87-A00-669-080 87-A00-764-001 87-A00-764-001 87-A00-764-001	RES,M/F RES,M/F RES,M/F	0.22-2W J 0.22-2W J 0.22-3W J 0.22-3W J 0.22-3W J		C1 C4 C5 C6 C7	87-010-387-080 87-A11-148-080 87-A11-148-080 87-A10-416-090 87-A10-416-090	CAP,TC CAP,TC CAP,E 6	70-25 SME U 0.1-50 ZF U 0.1-50 ZF 800-80 SMG 800-80 SMG
R244 WH101 WH102	87-A00-764-001 87-A90-460-010 87-A90-460-010	HLDR, WI	0.22-3W J RE 2.5-7P RE 2.5-7P		C8 C9 C10 C11 C12	87-A11-148-080 87-A11-148-080 87-A11-148-080 87-A11-148-080 87-A11-939-090	CAP,TC CAP,TC CAP,TC	U 0.1-50 ZF U 0.1-50 ZF U 0.1-50 ZF U 0.1-50 ZF 700-35 KMG
AMP 2F C.I	3				C13 C16	87-A11-939-090		700-35 KMG .3-50 SME
C101 C102 C103 C104	87-010-178-080 87-010-178-080 87-010-405-080 87-010-405-080	CAP,S 1 CAP,E 1	000P-50 KB C2012 000P-50 KB C2012 0-50 M 11L SME 0-50 M 11L SME		C16 C18 C19 C20	87-010-403-040 87-A11-148-080 87-A11-148-080 87-A11-148-080	CAP,TC	U 0.1-50 ZF U 0.1-50 ZF U 0.1-50 ZF U 0.1-50 ZF
C107	87-010-404-080		.7-50 M 11L SME		C21 C22	87-A11-148-080 87-A10-416-090		U 0.1-50 ZF 800-80 SMG
C108 C111 C112 C113 C114	87-010-404-080 87-010-176-080 87-010-176-080 87-010-260-080 87-010-260-080	CAP,S 68 CAP,S 68 CAP,E 4	.7-50 M 11L SME 80P-50 J SL 80P-50 J SL 7-25 M 11L SME 7-25 M 11L SME		C23 C24 C25	87-A10-416-090 87-A11-148-080 87-A11-148-080 87-A11-148-080	CAP,E 6 CAP,TC 1	800-80 SMG U 0.1-50 ZF U 0.1-50 ZF U 0.1-50 ZF
C114	87-010-200-000)-50 M 11L SME		C28 C29	87-A11-148-080 87-A11-148-080	CAP, TC	U 0.1-50 ZF U 0.1-50 ZF U 0.1-50 ZF
C116 C118 C119	87-010-405-080 87-010-196-080 87-010-196-080	CAP,E 1 C-CAP,S C-CAP,S	0-50 M 11L SME 0.1-25 ZF C2012 0.1-25 ZF C2012		C30 C31	87-A11-148-080 87-A11-148-080	CAP, TC	U 0.1-50 ZF U 0.1-50 ZF
C121	87-010-190-080	,	0.01-50 ZF C2012		C32 C33	87-A11-148-080 87-A11-148-080	CAP,TC	U 0.1-50 ZF U 0.1-50 ZF
C122 C151 C152 C153	87-010-190-080 87-012-368-080 87-012-368-080 87-A11-595-080	C-CAP,S C-CAP,S	0.01-50 ZF C2012 0.1-50 ZF 0.1-50 ZF 0.056-50 KB		C34 C35 C36	87-A11-148-080 87-A11-148-080 87-A11-148-080	CAP,TC	U 0.1-50 ZF U 0.1-50 ZF U 0.1-50 ZF
C154	87-A11-595-080	C-CAP,S	0.056-50 KB		C37 C38	87-A11-148-080 87-A11-148-080		U 0.1-50 ZF U 0.1-50 ZF
C155 C156 C160 C161	87-010-190-080 87-010-190-080 87-010-186-080 87-010-186-080	C-CAP,S C-CAP,S C-CAP,S	0.01-50 ZF C2012 0.01-50 ZF C2012 4700P-50 KB C2012 4700P-50 KB C2012		CN1 CN2 CN5	87-A61-110-010 8A-MTM-638-010 87-A60-619-010	CONN AS	V TID-A SY,7P LOW SUPPLY V 2MM JMT
C201	87-010-186-080	,	4700P-50 KB C2012	<u>^</u>	FB101 PR1	87-A90-562-010 87-026-682-080	PROTECT	9.5-17.5.5-28.5 BRH OR,10A 60V491
C202 C203 C204 C205	87-010-258-080 87-010-322-080 87-015-685-080 87-010-260-080	C-CAP,S CAP,E 1 CAP,E 4	2-35 M 11L SME 100P-50 J CH GRM 0-25 M 7L SRA 7-25 M 11L SME	<u>^</u>	PR2 PR3 PR4	87-026-682-080 87-026-682-080 87-026-682-080	PROTECT(OR,10A 491 SERIES 60V OR,10A 491 SERIES 60V OR,10A 491 SERIES 60V
C206 C208 C209	87-012-156-080 87-010-197-080 87-010-260-080	C-CAP,S	220P-50 J CH GRM 0.01-25 KB C2012 7-25 M 11L SME	<u>/!\</u> <u>^</u>	PR5 PR6 PR7 PR8	87-026-682-080 87-026-682-080 87-026-682-080 87-026-682-080	PROTECT(OR,10A 491 SERIES 60V OR,10A 491 SERIES 60V OR,10A 491 SERIES 60V OR,10A 491 SERIES 60V
C210 C211	87-010-260-080 87-010-178-080	CAP,E 4	7-25 M 11L SME 1000P-50 KB C2012	<u>/1\</u>	PR105	87-026-682-080		OR,10A 491 SERIES 60V
C212 C251 C252 C253 C258	87-010-178-080 87-012-368-080 87-A11-595-080 87-010-190-080 87-010-178-080	C-CAP,S C-CAP,S C-CAP,S C-CAP,S	0.1-50 ZF 0.056-50 KB 0.01-50 ZF C2012 1000P-50 KB C2012	<u>/\</u>	PR106 PR107 PR108 PT2 PT101	87-026-682-080 87-026-682-080 87-026-682-080 8A-NF8-673-010 8A-NHP-603-010	PROTECTO PROTECTO PT,SUB	OR,10A 491 SERIES 60V OR,10A 491 SERIES 60V OR,10A 491 SERIES 60V ANF-8 (H) KAMI I11480 ANH23
		5 5111 / 15	12 02012					

	REF. NO.	PART NO.	KANRI NO.	DESCRIPTION		REF. NO). PART NO.	KANRI NO.	DESCRIPTION
	RY2 S1 T1 T2	87-A91-300-010 87-A90-165-010 87-A60-317-010 87-A60-317-010	RELAY,A SW,SL 1 TERMINA	AC 12V ALA2PF12 L-2-3 SWS2301 AL, 1P MSC AL, 1P MSC		C556 C557 C559 C560 C561	87-012-145-080 87-010-183-080 87-010-196-080 87-010-177-080 87-010-177-080	C-CAP,S C-CAP,S C-CAP,S C-CAP,S	270P-50 J CH GRM 2700P-50 KB GRM 0.1-25 ZF C2012 820P-50 J SL C2012 820P-50 J SL C2012
	M C.B	87-049-919-010	CONN, 31	P EH V WHT		C562 C563 C564 C565	87-010-196-080 87-010-374-080 87-010-196-080 87-010-263-080	CAP,E 4' C-CAP,S	0.1-25 ZF C2012
G:	EQ C.B					C567	87-010-183-080	C-CAP,S	2700P-50 KB GRM
	C201 C202 C205 C207 C208	87-010-402-080 87-010-402-080 87-010-404-080 87-016-669-080 87-016-669-080	CAP, EI CAP, EI C-CAP,S	JECT 2.2-50V JECT 2.2-50V JECT 4.7-50V 3 0.1-25 KB 3 0.1-25 KB		C571 C572 C573 C577 CN551	87-016-460-080 87-016-460-080 87-016-460-080 87-010-196-080 87-A60-689-010	C-CAP,S C-CAP,S C-CAP,S	0.22-16 KB 0.22-16 KB 0.22-16 KB 0.1-25 ZF C2012 H GRY TUC-P07X-C1
	C209	87-016-460-080		S 0.22-16 B		DECK C.B			
(C210 C211 C212 C213	87-016-460-080 87-012-365-080 87-012-365-080 87-010-956-080	C-CAP,S	S 0.22-16 B S 0.027-25VBK S 0.027-25VBK AP,S 0.068-25B		CN502 SFR1 SOL1	87-099-756-010 87-024-581-010 82-ZM1-618-410	CONN,15P SFR,3.3K SOL ASSY	DIA 6H ,27
	C214	87-010-956-080		AP,S 0.068-25B		SOL2 SW1	82-ZM1-618-410 87-A90-248-010	SOL ASSY SW,MICRO	ESE11SH2CXQ
(C215 C216 C217 C218	87-010-197-080 87-010-197-080 87-010-198-080 87-010-198-080	CAP, CE	HIP 0.01 DM HIP 0.01 DM HIP 0.022 HIP 0.022		SW2 SW3 SW4 SW5	87-A90-248-010 87-A90-248-010 87-036-110-010 87-036-110-010	SW,MICRO SW,MICRO	
	C219 C220	87-010-183-080 87-010-183-080		G 2700P-50 B G 2700P-50 B			87-036-110-010	SW,MICRO SW,MICRO	
(C221 C222 C223	87-010-188-080 87-010-188-080 87-010-178-080	CAP, CHI	IP 6800P IP 6800P AP 1000P		SW8 SW9	87-A90-248-010 87-A90-248-010		ESE11SH2CXQ ESE11SH2CXQ
	C224	87-010-178-080		AP 1000P		HEAD-1 C.	В		
	C225 C226 C227 C228	87-010-182-080 87-010-182-080 87-010-112-080 87-010-196-080	C-CAP,S CAP, EI	S 2200P-50 B S 2200P-50 B LECT 100-16V APACITOR,0.1-25		CON301	85-ZM3-602-010 87-NF6-615-010	PWB,FLEX CONN ASS	
(C229 C230	87-010-322-080 87-010-322-080	C-CAP,S	3 100P-50 CH 3 100P-50 CH		HEAD-2 C.			
	C231 CN201	87-010-322-080 87-A60-546-010		3 100P-50 CH LP H GRY TUC-P11:	X-C1	CON351	85-ZM3-602-010 87-NF6-616-010	PWB,FLEX CONN ASS	
K.	EY CON C.	.В							
	C551 C552 C553 C554 C555	87-A10-060-080 87-A10-060-080 87-012-154-080 87-012-154-080 87-012-145-080	C-CAP,S C-CAP,S C-CAP,S	3 0.8-16 KB 3 0.8-16 KB 3 150P-50 J CH GI 3 150P-50 J CH GI 3 270P-50 J CH GI	RM				

〇チップ抵抗部品コード/CHIP RESISTOR PART CODE

チップ抵抗部品コードの成り立ち






チップ抵抗 Chip resistor

容量	種類	許容誤差	記号	寸法/Dime	ensions ((mm)		抵抗コード : A
Wattage	Type	Tolerance	Symbol	外形/Form	L	W	t	Resistor Code : A
1/16W	1005	± 5%	CJ		1.0	0.5	0.35	104
1/16W	1608	± 5%	CJ	L J t	1.6	0.8	0.45	108
1/10W	2125	± 5%	CJ		2	1.25	0.45	118
1/8W	3216	± 5%	CJ	r	3.2	1.6	0.55	128

TRANSISTOR ILLUSTRATION



ЕСВ


KTA1266GR KTC3198GR KTC3199GR





ЕСВ

CC5551



 $E \ C \ B$

DTC114ES 2SA933S



E C B

2SB1436(R)




ВСЕ

2SB1370E 2SB1649 2SD2562 FN1016 FP1016



ЕСВ

2SB1237Q



G D S

2SK3053



2SK2158 2SJ461-T1



2SA1235F 2SC2714O 2SC3052F CMBT5551


CMBT5401 CSD1306E DTA143EKA KRA102S





KRA104S KRA107S


KRC102S-RTK RT1N141C RT1P141C


RT1P144C RT1P441C

































IC BLOCK DIAGRAM



















IC, BU2092F




















ANODE CONNECTION

	136	12G	11G	10G	96~2G	1G
P1	510	0	S9	S8	5-7	S1
P2	B72	(AG)	854	B18	4-7	PRGM
Р3	B63	AG	845	B9	3-7	Al
P4	B71	() (EON:	B36	B17	2-7	EDIT
P5	B62	EON	B27	88	1-7	MANDOM
P6	870	()(RDS)	853	B16	5-6	(n@n)
P7	B61	RDS	B44	B7	4-6	MONO
P8	B69	S33	B35	B15	3-6	MHz
P9	B60	S32	826	B6	2-6	kHz
P10	B68	S31	B52	B14	1-6)
P11	B59	S30	B43	85	5-5	P
P12	867	S29	B34	B13	4-5	Ĉ
P13	B58	S28	B25	B4	3-5	8
P14	B66	S34	B51	B12	2-5	8
P15	B57	S26	842	B3	1-5	(REC)
P16	B65	S25	B33	B11	5-4	DIONR
P17	B56	S20	B24	B2	4-4	
P18	B64	S36	B50	B10	3-4	
P19	B55	S21	B41	B1	2-4	Í
P20	S14	S37	832	S6	1-4	23
P21	S13	S27	B23	S5	5-3	3
P22	S12	S22	B49	S4 ·	4-3	4
P23	S11	S38	B40	S3	3-3	5 6 7
P24	S15	S24	B31	S7	2-3	6
P25	(ROCK)	S23	B22	(DISCO)	1-3	
P26	(POP)	S39	848	(LIVE)	5-2	8
P27	(LATIN)	S19	B39	(STADIUM)	4-2	9
P28	(CLASSIC)	S35	B30	(HALL)	3-2	10
P29	SLEEP	S16	B21	() (6)	2-2	11
P30	REC	S17	B47	() (#)	1-2	12
P31	0	S18	B38	b #	5-1	13
P32		d	B29	AUTO	4-1	14
P33	M2	е	B20	VF S	3-1	15
P34	M 33	С	846	180 T 180 LAND	2-1	16
P35	M4	g	B37	CERTIFICAL)	1-1	17
P36	SCH DOWNERS	f	B28	_	B73	18
P37	DIGITAL	b	B19	*****	B74	19
P38	****	а	-		. 875	20
P39	4344	-			S2	•

Pin No.	Pin Name	I/O	Description
1	CLK	О	Common serial CLOCK output.
2	DATA	О	Common Serial DATA output.
3	STB	О	Common serial STROBE output.
4	CS-RHYTHM	О	Rhythm IC chip select output.
5	GEQ-CE	О	GEQ IC chip enable output.
6	HP-MUTE	I	Headphone plug-in detect input. (Output "L" at HOLD)
7	O-POWER	0	System power ON/OFF output. (Active "H")
8	PLL-CE	О	Tuner PLL IC chip enable output.
9	O-MUTE	О	System mute ON/OFF output.
10	I-MIC	I	Auto-VF MIC level special A/D input. (Output "L" at HOLD)
11	RESET	I	Reset input.
12	VOL-JOG	I	Main volume JOG rotary encoder A/D input.
13	MULTI-JOG	I	MULTI JOG rotary encoder A/D input.
14	VSS1	_	Connected to GND.
15	CF 1		
16	CF2	_	9.43MHz oscillator circuit.
17	VDD1	_	Power supply.
18	HOLD	I	Power supply voltage detect A/D input.
19 ~ 22	KEY 1 ~ 4	I	KEY 1 ~ 4 A/D input. (Output "L" at HOLD)
23	I-CDSW	I	CD mechanism SW A/D input. (Output "L" at HOLD)
24	I-DISH	I	CD turntable photo sensor A/D input. (Output "L" at HOLD)
25	I-SPEANA	I	SPEANA level A/D input. (Output "L" at HOLD)
26	I-RDSCLK/I-WRQ	I	TUNER RDS IC CLK (INT2) input / CD WRQ input. (Output "L" at HOLD&INI)
27	I-TU-SIG/MS	I	Tuner tuning signal level A/D input / Deck MS SENS. (Output "L" at HOLD)
28	I-TMBASE	I	Timebase clock (8Hz) input. (Output "L" at HOLD)
29	I-RMC	I	Remote control signal input. Active: "L". (Output "L" at HOLD)
30 ~ 42	G13 ~ G1	0	FL grid G13 ~ G1 output.
43 ~ 45	P39 ~ P37	0	FL segment P39 ~ P37 output.
45 ~ 45	VDD3	_	Power supply.
47			77.7
	P36/SPEANA A	0	FL segment P36 output / SPEANA band select output (A).
48	P35/SPEANA B P34/SPEANA C	0	FL segment P35 output / SPEANA band select output (B). FL segment P34 output / SPEANA band select output (C).
49	<u> </u>		• • •
50	P33	О	FL segment P33 output.
51	VP	-	Power supply for FL.
52 ~ 59	P32 ~ P25	О	FL segment P32~ P25 output.
60	P24/NO AC-DEMO	I/O	FL segment P24 output / NO AC-DEMO at AC-IN diode input. (No store DEMO mode.)
61	P23/CASINO-DEMO	I/O	FL segment P23 output / CASINO-DEMO select diode input.
62	P22/NO-ECO	I/O	FL segment P22 output / NO-ECO select input.
63	P21/NO-RHYTHM	I/O	FL segment P21 output / NO-RHYTHM select diode input.
64	P20/AC3-DPL	I/O	FL segment P20 output / AC3-DPL select diode input. (Not used.)

Pin No.	Pin Name	I/O	Description	
65	P19/K-CON	I/O	FL segement P19 output / K-CON select diode input.	
66	P18/RDS	I/O	FL segement P18 output / RDS select diode input.	
67	P17/FM1	I/O	FL segment P17 output / FM1 select diode input. (Not used.)	
68	P16/SW	I/O	FL segment P16 output / SW step initial diode input.	
69	P15/LW	I/O	FL segment P15output / LW stereo select diode input.	
70	P14/AM-10K	I/O	FL segment P14 output /AM-10K select diode input.	
71	P13/AM-ST	I/O	FL segment P13 output / AM-ST select diode input. (Not used.)	
72	VDD4	_	Power supply.	
73~76	P12~P9	О	FL segment P12~P9 output.	
77	P8/REA	I/O	FL segment P8 ouput / REC enable (A) switch input (active: "L").	
78	P7/CST1	I/O	FL segment P7 output / Cassette (1) switch.	
79	P6/CAM1	I/O	FL segment P6 output / CAM (1) switch input (active: "L").	
80	P5/AUTO2	I/O	FL segment P5 output / Auto stop reel (2) pulse input.	
81	P4/AUTO1	I/O	FL segment P4 output / Auto stop reel (1) pulse input.	
82	P3/CAM2	I/O	FL segment P3 output / CAM (2) switch input. (active:"L").	
83	P2/REB	I/O	FL segment P2 output / REC enable (B) switch input. (active:"L").	
84	P1/CST2	I/O	FL segment P1 output / Cassette (2) switch input. (active:"L").	
85	K-SCAN	0	Key scan output. (active:"L").	
86	SOL1	0	DECK (1) solenoid ON/OFF output.	
87	SOL2	0	DECK (2) solenoid ON/OFF output.	
88	O-MOTOR	0	Deck motor \overline{ON}/OFF output .	
89	VSS2	_	Connected to GND.	
90	VDD2	_	Power supply.	
91	O-DISHREV	0	CD turn table dish reverse output.	
92	O-DISHFWD	О	CD turn table dish forward output.	
93	O-OPEN	О	CD tray open output.	
94	O-CLOSE	0	CD tray close output.	
95	IFC-TU/I-SQDATA	I	Tuner tune/IF count input (active: "L") / CD SUB-Q data input.	
06	Ī-STEREO/I-DRF	1/0	Tours at any datast is not (action III III) / DDE is not	
96	(O-CLK-VCD)	I/O	Tuner stereo detect input (active "L") / DRF input.	
	O-DATA(CD)/	I/O	CD IC control data output / Tuner RDS data input. (Not used.)	
97	I-RDS DATA		22 22 Control data curput / Tance 1250 data input. (1 tot used.)	
98	CD-CE/	1/0		
	IO BUSY (VCD)	I/O	CD chip enable output.	
99	CLK (CD)	О	CD IC control clock output.	
100	STB(SHIFT)	0	Shift register strobe output.	

ADJUSTMENT < TUNER/DECK/DISPLAY>

< TUNER SECTION >

1. Clock Frequency Check

Settings: • Test point: TP2 (CLK)

Method: Set to MW 1602kHz and check that the test point is

2052kHz ± 45 Hz.

2. MW VT Adjustment

Settings: • Test point: TP1 (VT)

• Adjustment location: L953

Method: Set to MW 1710kHz and adjust L953 so that the test point becomes $8.0V \pm 0.05V$. Then set to MW 530kHz

and check that the test point is more than 0.3V.

3. MW Tracking Adjustment

Settings: • Test point: TP8(Lch), TP9(Rch)

• Adjustment location :

L952603kHz

TC941 1404kHz

Method: Set up TC941 to center before adjustment. The level at 603kHz is adjusted to max. by L952. Then the level at

1404kHz is adjusted to max. by TC941.

4. AM IF Adjustment

Settings: • Test point: TP8(Lch), TP9(Rch)

• Adjustment location :

L802405kHz

5. SW VT Adjustment

Settings: • Test point: TP1 (VT)

> Adjustment location: L942

Method: Set to SW 17.9MHz and adjust L942 so that the test point becomes $8.0V \pm 0.2V$. Then set to SW 5.73MHz

and check that the test point is more than 0.3V.

6. SW Tracking Adjustment

Settings: • Test point: TP8(Lch), TP9(Rch)

• Adjustment location:

L941 5.9MHz TC942 17.9MHz

Method: Set up TC942 to center before adjustment. The level at 5.9MHz is adjusted to max. by L941. Then the level at

17.9MHz is adjusted to max. by TC942.

7. FM VT Check

Settings: • Test point: TP1 (VT)

Method: Set to FM 87.5MHz, 108.0MHz and check that the

test point is more than 0.5V (87.5MHz) and less than

8.0V (108.0MHz)

8. FM Tracking Check

Settings: • Test point: TP8(Lch), TP9(Rch)

Method: Set to FM 98.0MHz and check that the test pooint is less

than 9dBuV

9. DC Balance / Mono Distortion Adjustment

Settings: • Test point: TP3, TP4 (DC Balance)

TP8(Lch), TP9(Rch)

(Distortion)

• Adjustment location: L801

• Input level: 60dBuV

Method: Set to FM 98.0MHz and adjust L801 so that the

distortion is minimum. Then check the voltage between

TP3 and TP4 is 0V± 0.3V

< DECK SECTION >

10. Tape Speed Adjustment

Settings: • Test tape: TTA-100(3kHz)

• Test point : TP10(Rch), TP11(Lch)

• Adjustment location: SFR1

Method: Play back the test tape and adjust SFR1 so that the

frequency counter reads 3000Hz \pm 5Hz(FWD) and \pm

45Hz(REV) with respect to forward speed.

11. Head Azimuth Adjustment

Settings: • Test tape: TTA-300 (315/10kHz)

• Test point : TP10(Rch), TP11(Lch)

• Adjustment location: Head azimuth

adjustment screw

Method: Play back the 10kHz signal of the test tape and adjust

screw so that the output becomes maximum. Next, perform on each FWD PLAY and REV PLAY mode.

12. PB Frequency Response Check (DECK 1, DECK 2)

Settings: • Test tape: TTA-300 (315/10kHz)

• Test point : TP10(Rch), TP11(Lch)

Method: Play back the 315Hz and 10kHz signals of the test tape and check that the output ratio of the 10kHz signal with

respect to that of the 315Hz signal is within $0 \pm 2dB$.

13. PB Sensitivity Adjustment (DECK 1, DECK 2)

Settings: • Test tape: TTA-200 (400Hz)

• Test point : TP10(Rch), TP11(Lch) • Adjustment location: SFR301 (DECK 1, Lch)

SFR302 (DECK 1, Rch)

SFR303 (DECK 2, Lch)

SFR304 (DECK 2, Rch)

Method: Play back the test tape and adjust SFRs so that the output level of the test points become 245mV±10mV.

14. REC/PB Frequency Response Adjustment (DECK 2)

Settings: • Test tape: TTA-602 (Normal)

• Test point : TP10(Rch), TP11(Lch)

• Input signal: 1kHz / 10kHz (LINE IN)

• Adjustment location: SFR351 (Lch)

SFR352 (Rch)

Method: Apply a 1kHz signal and REC mode. Then adjust OSC attenuator so that the output level at the test points becomes 12.5mV. Record and play back the 1kHz and

10kHz signals and adjust SFRs so that the output level of the 10kHz signals becomes $0dB \pm 0.5dB$ with respect

to that of the 1kHz signal.

15. REC/PB Frequency response Check (DECK 2)

Settings: • Test tape: TTA-615 (CrO₂)

TP10(Rch), TP11(Lch) • Test point :

• Input signal : 1kHz/10kHz (LINE IN)

Method: Apply a 1kHz signal and REC mode. Then adjust OSC attenuator so that the output level at the test points

becomes 12.5mV. Record and play back the 1kHz and 10kHz signals and check that the output is 0dB \pm 2dB.

16. REC/PB Sensitivity Adjustment (DECK 2)

Settings : • Test tape : TTA-602 (Normal)

• Test point : TP10(Rch), TP11(Lch)

• Input signal : 1kHz (LINE IN)

• Adjustment location : SFR305 (Lch)
SFR306 (Rch)

Method : Apply a 1kHz signal and REC mode. Then adjust OSC attenuator so that the output level at the test points becomes 125mV. Record the play back the 1kHz signal and adjust SFRs so that the output level becomes 0dB \pm

0.5dB

17. REC/PB Sensitivity Check (DECK 2)

Settings : • Test tape : $TTA-615 (CrO_2)$ • Test point : TP10(Rch), TP11(Lch)• Input signal : 1kHz (LINE IN)

Method: Apply a 1kHz signal and REC mode. Then adjust OSC attenuator so that the output level at the test points becomes 125mV. Record and play back the 1kHz signal and check that the output is 0dB \pm 1.5dB.

< DISPLAY SECTION >

18. μ-CON OSC Adjustment


Settings: • Test point: TP1(K-SCAN), TP2 (GND)

• Adjustment location: L101

Method : Insert AC plug with pressing TUNER function key.

Adjust L101 so that the frequency across the test

point is 208.8Hz ± 0.2 Hz.





MECHANICAL PART LIST 1/1

REF. NO.	PART NO.	KANRI DESCRIPTION NO.	REF. NO.	PART NO.	KANRI DESCRIPTION NO.
1	00 3702 000 010	****	4.6	03 3702 000 010	
	88-NF3-090-010	•		8A-NF3-208-010	•
	8A-NH4-042-010	•		87-NF4-221-010	
3	8A-NF3-029-010	BOX, CASS R	48	87-A91-423-010	FAN,AD0612DS-D70GL
4	8A-NF3-040-010	PANEL, CASS R	∠!\ 49	87-A80-148-010	AC CORD ASSY, E BLK
5	8A-NF3-059-010	WINDOW, CASS R	50	87-A90-562-010	F-BEAD,9.5-17.5-28.5 BRH
6	8A-NF3-039-010	PANEL, CASS L	51	87-085-185-010	BUSHING, AC CORD (E)
7	8A-NF3-058-010			8A-NF8-206-010	
	8A-NF3-028-010	BOX, CASS L		8A-NF3-209-010	
9		REFLECTOR, CASS L		8A-NF3-211-010	
	81-532-080-010	LABEL, CASS. COMPT		8A-NHP-212-010	
10	01-532-000-010	LABEL, CASS. COMPI	55	0A-NHP-212-010	HLDR, PWB HZ1.5
11	8A-NF3-091-010	REFLECTOR, CASS R	5.6	8A-NF3-229-210	HLDR, BRACKET
	8A-NF3-049-010	PANEL, KEY-CD		8Z-NF3-210-010	
	8A-NF3-048-010	•		8A-NF3-212-010	•
	8A-NF3-047-010	PANEL,CD		84-ZG1-245-210	•
15	8A-NF3-071-010	KEY,CD	60	8A-NH4-026-110	CABI,BOTTOM
1.0	03 37772 000 010	DDD1 D0000 00	<i>C</i> 1	0= 1=2 040 010	gorran norman
	8A-NF3-089-010	·		8Z-NF3-048-010	•
	8A-NF3-203-010	GUIDE, LED-CD		82-NF5-219-010	
18	87-NF4-216-010	HLDR,LOCK 1	63	87-NF4-217-110	HLDR,LOCK 2
19	86-NF9-224-010	SPR-C,LOCK	64	87-064-185-010	HLDR, WIRE
20	82-NF5-229-010	PLATE, LOCK	65	8A-NF3-223-010	HLDR, FAN
	87-NF8-220-010			87-A91-314-110	
22	82-NF5-218-010	SPR-T,EJECT 1 (SIN)	67	8A-NHP-011-010	CABI,REAR VT-99
23	8A-NF3-082-010	KNOB, RTRY JOG	68	8A-NF3-228-010	HLDR,PWB-PT
24	8A-NF3-087-010	REFLECTOR, JOG	69	8A-NF3-027-010	CABI, STEEL
	8A-NF3-077-010	RING, JOG H	A	87-067-703-010	
26	8A-NF3-081-010	KNOB, RTRY VOL	В	87-067-581-010	TAPPING SCREW, BVT2+3-15
27	8A-NF3-076-010	RING, VOL	C	87-721-097-410	QT2+3-12 GLD
28	8A-NHP-001-010	CABI, FR	D	87-591-095-410	TAPPING SCREW, QIT+3-8 (GLD)
	8A-NHP-051-010	WINDOW, DISP VT-99	E	87-B10-190-010	. ~
	8A-NHP-031-010	PANEL, FR H	<u>-</u> ਸ	87-067-689-010	
30	OA WIII OJI OIO	I ANDE, I R	Ī.	07 007 005 010	TATTING BEREW, BVII'S 0
31	8A-NF3-063-010	KEY ASSY, OPE	G	87-067-761-010	TAPPING SCREW, BVT2+3-10
	8A-NH4-066-010	KEY, PBC	H	87-NF4-224-010	
	8A-NFR-065-010	KEY, PRO-LOGIC	I	87-721-096-410	
	8A-NF3-067-010	KEY, BBE	J	87-067-758-010	
35	8A-NF3-061-010	KEY, GEQ	K	87-067-975-010	S-SCREW,IT+4-8
36	8A-NF3-062-010	KEY, DSP	L	87-067-641-010	UTT2+3-8(W/O SLOT)BL
	8A-NF3-201-010	GUIDE, LED-FUNC	M	87-067-579-010	
			M N		
	8A-NFR-072-010	KEY, FUNC PRO	N	87-B10-287-010	BVT2+3-33 W/O SLOT
	8A-NF3-088-010	REFLECTOR, FUNC			
40	8A-NF3-068-010	KEY, JOG			
<i>1</i> .1	8A-NF3-069-010	KEY,SPICE			
	8A-NF3-070-010	KEY, ECO			
	8A-NF3-213-110	HLDR,HT-SINK L			
	8A-NF3-214-010	HLDR, HT-SINK R			
45	8A-NF3-210-010	HLDR,SIDE L			

COLOR NAME TABLE

OOLOIT IN TIVIL	. 1/\DLL				
Basic color symbol	Color	Basic color symbol	Color	Basic color symbol	Color
В	Black	С	Cream	D	Orange
G	Green	Н	Gray	L	Blue
LT	Transparent Blue	N	Gold	Р	Pink
R	Red	S	Silver	ST	Titan Silver
Т	Brown	V	Violet	W	White
WT	Transparent White	Y	Yellow	YT	Transparent Yellow
LM	Metallic Blue	LL	Light Blue	GT	Transparent Green
LD	Dark Blue	DT	Transparent Orange	GM	Metallic Green
YM	Metallic Yellow	DM	Metallic Orange		





TAPE MECHANISIM PARTS LIST 1/1


REF. NO.	PART NO.	KAN NO.	
1	82-ZM3-301-610	1H	CHAS ASSY, M2
2	82-ZM1-258-210	0E	SPR-T, PINCH L
3	82-ZM1-341-210	1A	LVR ASSY, PINCH L2
4	82-ZM1-333-210	0E	PLATE, LINK2
5	82-ZM1-266-310	0E	LVR, DIR
6	82-ZM1-214-010		
7	82-ZM1-206-910		
8			PULLEY, COUPLER M3
9	82-ZM1-269-210		
10	82-ZM1-219-110	0E	SPR-T, LINK
	82-ZM1-210-110		
	82-ZM1-213-010		
13			
			S-SCREW, AZIMUTH L
15	82-ZM1-314-110	UΕ	PLATE, HEAD
16	82-ZM1-208-310	0E	HLDR, HEAD
17			
18	82-ZM3-342-010	0E	BELT, SBU MOT 3
19	82-ZM1-222-210	0E	LVR, PLAY
20	82-ZM1-217-410	0E	REEL TABLE
	82-ZM1-244-510		
	82-ZM1-285-410		
23	82-ZM1-257-010	0E	SPR-T,CAS
24	82-ZM1-241-310		
25	82-ZM1-242-010	0E	LVR, CAS
26	82-ZM1-243-010		
27			LVR ASSY, PINCH R2
28	82-ZM1-259-210		
29	82-ZM1-240-110	0E	LVR, REC(*)
30	80-ZM6-243-010	0E	SH 1.75-3.6-0.5 SLT
31	82-ZM1-255-310	0E	SPR-E,LVR DIR
32	82-ZM3-305-210	0E	GEAR, CAM M2
33	82-ZM1-227-310		
	82-ZM3-306-110	0E	LVR,FR M2
35	82-ZM1-265-310	0E	SPR-E, TRIG
36	82-ZM3-339-110	0E	SHAFT, COUPLER N3

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
38 39 40	86-ZM1-206-010 82-ZM1-322-010 82-ZM1-220-210 82-ZM3-616-010 82-ZM1-216-410	0E SPR-T,1 0E GEAR,11 0E RING M	FR 60 DLER AGNET 4
42 43 44	87-A90-820-010 87-A90-821-010 82-ZM1-225-210 82-ZM1-226-010 82-ZM3-333-310	1H HEAD, RI 0E GEAR, FI 0E GEAR, RI	PH HADKH56 FPC R EW
47 47	82-ZM1-338-110 82-ZM1-237-610 09-001-420-010 82-ZM3-234-310	1A FLY-WHI 0E FLY-WHI	L ASSY,R L,R ASSY
51	82-ZM3-329-410 82-ZM1-618-410 87-045-347-010 82-ZM3-221-210 85-ZM3-202-010	1B SOL ASS 1H MOT, SHO 0E PULLEY	SY,27 J2L 70 ,MOT 2M
	80-ZM6-207-010 82-ZM3-318-110 87-B10-043-010 82-ZM3-334-010	OE S-SCREWOE W-P, 0.5	W W,MOTOR M2 99-4-0.25 SLT

SPEAKER DISASSEMBLY INSTRUCTIONS


Type.1

Insert a flat-bladed screwdriver into the position indicated by the arrows and remove the panel. Remove the screws of each speaker unit and then remove the speaker units.




Type.2

Remove the grill frame and four pieces of rubber caps by pulling out with a flat-bladed screwdriver. Remove the screws from hole where installed rubber caps. Insert a flat-bladed screwdriver into the position indicated by the arrows and remove the panel. Remove the screws of each speaker unit and then remove the speaker units.




Type.3

Insert a flat-bladed screwdriver into the position indicated by the arrows and remove the panel. Turn the speaker unit to counter-clockwise direction while inserting a flat-bladed screwdriver into one of the hollows around speaker unit, and then remove the speaker unit. After replacing the speaker unit, install it turning to clockwise direction until "click" sound comes out.



Type.4




TOOLS

- 1 Plastic head hammer
- ② (⊖) flat head screwdriver
- 3) Cut chisel

How to Remove the PANEL, FR

- Insert the (⊖) flat head screwdriver tip into the gap between the PANEL, FR and the PANEL, SPKR. Tap the head of the (⊖) flat head screwdriver with the plastic hammer head, and create the clearance as shown in Fig-1.
- Insert the cut chisel in the clearance, and tap the head of the cut chisel with plastic hammer as shown in Fig-2, to remove the PANEL, FR.
- Place the speaker horizontally. Tap head of the cut chisel with plastic hammer as shown in Fig-3, and remove the PANEL, FR completely.



How to Attach the PANEL, FR

Attach the PANEL, FR to the PANEL, SPKR. Tap the four corners of the PANEL, FR with the plastic hammer to fit the PANEL, FR into the PANEL, SPKR completely.

SPEAKER PARTS LIST SX-WWST77 <YJSL>

REF. NO	. PART NO.	KANRI	DESCRIPTION	REF. NO.	PART NO.	KANRI	DESCRIPTION
		NO.				NO.	
1	8A-NS4-001-010	PANEL, FR		11	88-NS5-611-010	CORD, SP	KR B/L
2	8A-NS4-007-010	PANEL, TW	L	12	8A-NS4-019-010	PANEL, D	UCT RING G
3	8A-NS4-006-010	PANEL, TW	I R	13	8A-NS4-004-010	PANEL,D	UCT
4	8A-NS4-013-010	PROTECTO	OR,TW				
5	88-NS3-602-110	SPKR,W 2	00				
6	8A-NS4-602-010	SPKR,M 1	20				
7	8A-MS2-605-110	SPKR,TW	60				
8	88-NSK-610-010	SPKR, CER	AMIC ASSY				
9	8A-NS4-009-010	GRILLE, F	RAME ASSY				
10	88-NS5-610-010	CORD, SPK	T.R.				

SPEAKER PARTS LIST SX-CR2700 <YJSC>

NOTE: This SX-CR2700 Speaker contains SX-C2700 (Center Speaker) and SX-R2700 (Rear Speaker)

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
1	8A-AS3-001-010	CABI,FR	
2	8A-AS3-003-010	GRILLE,	FRAME ASSY
3	8A-AS3-006-010	CABI,FR	C
4	8A-AS3-007-110	CABI, REA	AR C
5	8A-AS3-008-010	GRILLE,	FRAME ASSY C
6	8A-AS3-601-010	SPKR,100)
7	8A-AS3-602-010	SPKR,100)
8	8A-AS3-011-010	TERMINAI	L, ASSY
9	8A-AS3-603-010	SPKR, CO	ORD 20M

ACCESORIES / PACKAGE LIST

REF. NO.	PART NO.	KANRI NO.	DESCRIPTION
1	8A-NHP-901-010	IB,H E	C-H M
2	87-006-226-010	AM LOO	P ANT CO
3	87-043-115-010	ANT, FE	EDER FM
4	87-050-103-010	CORD,	PIN 1PY1.5M
5	87-A90-119-010	ANT,WI	RE SW (5M)
<u>^</u> 6 7	87-A91-017-010 8Z-NHT-702-010		ONVERSION JT-0476 T,RC-ZAS08

アイワ株式会社 〒110-8710 東京都台東区池之端1-2-11 ☎03(3827)3111 (代表) **AIWA CO.,LTD.** 2-11, IKENOHATA 1-CHOME, TAITO-KU, TOKYO 110, JAPAN TEL:03 (3827) 3111 9620450 9630472 0251431 Printed in Singapore